TECHNICAL SERVICE BULLETIN

75-C-9



October, 1975

SUBJECT:		MODELS:		
			(0)	
TRANS	SFER DECALS		ALL	

Adequate adhesion of transfer decals on various Triumph models will not be achieved unless the panels are cleaned and the transfer applied to a panel which has been normalized at a temperature of 60°F. minimum.

All dealers are reminded that it is necessary for the vehicle body panel to attain the above temperature before application of the decals, and this may be achieved by allowing a vehicle to remain in normal workshop temperane h rticula ture for at least one hour prior to application. requirement is particularly important during winter months.