## SERVICE & PARTS TECHNICAL INFORMATION



## Trium

August, 1978

SUBJECT:

MODELS:

HEADLAMP OPERATION

A thorough check of the ground system should be completed in the event that when operating the headlamp switch, relay chatter may occur accompanied by flashing instrument warning lights.

These symptoms are more likely to occur under conditions of heavy load on the electrical system; for example, heater fan and wipers, air conditioning, etc. all in operation at the same time. Pay particular attention to the following points:

- Ensure that the battery to body ground point is sound, cleaning away any paint so that the shakeproof washer will bite into the metal when the fixing bolt is tightened.
- COLUMN TOTOLOGY Totol Check the multiple ground wires located in the area of the wiper motor for continuity.

T-03-78/164