ITEM T80/023

All dealer technicians should be aware of the importance of proper grounding of a vehicle electrical circuit.

An important area which is sometimes overlooked is the engine to frame or body ground strap and connections.

If a satisfactory ground is not made the current will find its own ground via accelerator cables or handbrake cables with subsequent damage to inner and outer cables.

On TR7 and TR8 models, the ground strap is located at the right side of the bell housing.