
## ITEM T81/07 SUBJECT: FUEL PUMP ELECTRICAL FEED (OIL PRESSURE SWITCH) MODELS: TR8 (Carburetted)

oided with why

On TR8 vehicles from VIN 200001 onwards the electrical feed to the fuel pump is taken from the starter solenoid and the oil pressure switch. The pump will only operate when the engine is being cranked or is running with sufficient oil pressure. An oil pressure failure in the engine will stop the fuel pump operation.

The oil pressure switch has 3 terminal connections, the part number is GPS 123.



Н.С.Т.